

**Tool model**  
**Tool Status**

SB156SL-1-E  
active

**BOSTITCH®**




Chart Ref	Spare part code	Description	Status	Previous Part Code 1	Previous Part Code 2
1	<a href="#">OA51311I</a>	Schoulder screw	active		
2	<a href="#">OA1162E1</a>	EXHAUST COVER	fut disc		
3	<a href="#">S06P000900</a>	O-RING	active		
4	<a href="#">174047</a>	SCREW,SHCS,M5x0.8x25	active		
5	<a href="#">000000-00</a>	NO LONGER AVAILABLE	disc		
6	<a href="#">P1630000340</a>	DEFLECTOR	active		
7	<a href="#">1FP0018</a>	O-RING	active		
8	<a href="#">PA11511I</a>	PACKING	active		
9	<a href="#">PB1021W1</a>	SEAL	active		
10	<a href="#">PB1041S1</a>	Spring	active		
11	<a href="#">PA1051W1</a>	HD. VALVE PISTON	active		
12	<a href="#">1FZ0006</a>	O-RING	active		
13	<a href="#">1FP2025</a>	O-RING	active		
14	<a href="#">1FP2038</a>	O-RING	active		
15	<a href="#">PA1091E1</a>	COLLAR	active		
16	<a href="#">1FA0142</a>	O-RING	fut disc		
17	<a href="#">1FP0032</a>	O-RING	active		
18	<a href="#">G0213600</a>	Driver Unit	active		
19	<a href="#">1FA0130</a>	O-RING	active		
20	<a href="#">P1632000700</a>	CYLINDER	active		
21	<a href="#">1FP0042</a>	O-RING	active		
22	<a href="#">PA1111O1</a>	BUMPER	active		
23	<a href="#">P1745201262</a>	Joint Guide	active		
24	<a href="#">PB205BA1</a>	TRIGGER VALVE UNIT	active		
25	<a href="#">PB2081A1</a>	TRIGGER UNIT	active		
26	<a href="#">JA2071W1</a>	STEPPED PIN	active		

Chart Ref	Spare part code	Description	Status	Previous Part Code 1	Previous Part Code 2
27	<a href="#">174073</a>	O-RING, 2.05MMx2.62MM	active		
28	<a href="#">000000-00</a>	NO LONGER AVAILABLE	disc		
29	<a href="#">PB5141E1</a>	SAFETY GUIDE	active		
30	<a href="#">PA3301A1</a>	FRAME	active		
31	<a href="#">OA3651I1</a>	PACKING	active		
32	<a href="#">OA3611D1</a>	END CAP	active		
33	<a href="#">1A105201</a>	HEX. SOC. HD. BOLT	active		
34	<a href="#">P1735200262</a>	Spacer	active		
35	<a href="#">P1800000463</a>	Magazine B	active		
36	<a href="#">P1806300165</a>	Driver Guide Cover	active		
37	<a href="#">S0110418100</a>	Hex. Soc. Hd. Bolt	active		
38	<a href="#">S0110408100</a>	Hex.Soc.Hd.Bolt	active		
39	<a href="#">JV4132I1</a>	STOP PLATE	fut disc		
40	<a href="#">S0310410100</a>	FLAT HD.SOC.SCREW	active		
41	<a href="#">P1745200462</a>	Pusher	active		
42	<a href="#">JV4812E1</a>	SLIDE	fut disc		
43	<a href="#">JV4902I1</a>	FIXED PARTS	fut disc		
44	<a href="#">JV4142S1</a>	SPRING	fut disc		
45	<a href="#">JV4152I1</a>	SPRING GUIDE	fut disc		
46	<a href="#">P1806300665</a>	Magazine Unit	active		
47	<a href="#">1I1025</a>	E-RING	fut disc		
48	<a href="#">JV4182W1</a>	CLICK LEVER PIN	fut disc		
49	<a href="#">JV4612W1</a>	BUSHING	fut disc		
50	<a href="#">JV4192S1</a>	SPRING	fut disc		
51	<a href="#">P1736300865</a>	Click Lever	active		
52	<a href="#">JV426201</a>	END COVER	fut disc		
53	<a href="#">JV4272W1</a>	PIN	fut disc		
54	<a href="#">JV4712W1</a>	FIXED PLUG	fut disc		
55	<a href="#">P1746301365</a>	Tail Hanger	active		
56	<a href="#">MHE4070-100</a>	ELASTIC STOP NUT,M4	active		
57	<a href="#">1L106201</a>	BUTTON HD. SOC. SCREW	fut disc		
58	<a href="#">000000-00</a>	NO LONGER AVAILABLE	disc		
59	<a href="#">1G106</a>	LOCK NUT	fut disc		
60	<a href="#">PB5092S1</a>	SPRING	fut disc		
61	<a href="#">P1805200562</a>	Safety A	active		
62	<a href="#">JA5161W1</a>	SETTING KNOB	active		
63	<a href="#">JA5092S1</a>	SPRING	active		
64	<a href="#">1I1020</a>	E-RING	active		
65	<a href="#">G3801762</a>	Safety B Unit	active		
66	<a href="#">P1780002466</a>	Safety Cover	active		
67	<a href="#">P0635200762</a>	Shoulder Screw	active		
68	<a href="#">P1785202162</a>	Bush	active		
69	<a href="#">P1800000866</a>	Safety Sleeve	active		
70	<a href="#">P0780000800</a>	Nails Of Inspection	active		